

FUYL Tower

Charge your devices here

```
Type locker number  
to lock/unlock █
```

Identify an unused/
unlocked locker.

```
Select Locker  
12 █ OK
```

Type selected locker and
press OK. Locker must be 1-15.

```
Locker is free: 12  
PIN to reserve: *** █
```

Enter a 4 digit PIN. If the locker is not
free, display will indicate LOCKED.

```
Locker is free: 12  
Confirm PIN: *** █
```

Confirm your PIN
to proceed further.

```
Insert items & push  
firmly on door █
```

Place mobile device/s in the locker
and connect to charging socket.

```
Locking... █
```

Close the door firmly and
the door will latch and lock.

UNLOCKING: Select your locker by typing in locker number and enter your PIN. The locker will unlock. Remove your devices.